



FL75

For warranty and distributor information in your country, visit: www.COASTportland.com

INSTRUCTIONS FOR COAST FL75 HEADLAMP:

BATTERY INSTALLATION:

The FL75 uses three AAA alkaline batteries located in the rear of the headlamp. To access the battery compartment, hinge the headlamp downward to reveal the rear of the headlamp body. Once the rear of the headlamp is revealed, pull the locking mechanism up to unlock the battery compartment. Insert the batteries in the direction indicated inside the headlamp, close the battery compartment door until it 'clicks' shut, and hinge the headlamp back towards the reflective strap. Never mix old and new batteries. Remove batteries before storing headlamp for extended periods of non-use.

Note: The FL75 in clam packaging comes with batteries pre-installed.

WHITE & RED LED LIGHT OPERATION:

To turn on the white light, depress the power switch on the top-right side of the headlamp while worn to enter "High" white LED light mode. Depressing the same button a second time soon after will switch the headlamp to "Medium" white LED light mode. A third depression of the button soon after will turn the headlamp into "Low" white LED light mode. To shut down the light, depress the power switch a fourth and final time, or sometime after the previous depression.

To turn on the red light, depress the power button on the top-left side of the headlamp while worn to enter red LED light mode. To shut down the light, depress the same button a second time.

Due to possessing separate buttons, LEDs may be powered individually or at the same time.

FOCUS AND BEAM POSITION ADJUSTMENT:

This headlamp is equipped with COAST's Pure Beam Focusing Optic System with Twist Focus, which allows the user to choose between a broad flood beam and a focused Bulls-Eye Spot beam for long distance illumination. To adjust the beam into flood light mode, rotate the Twist Focus Ring bezel around the lens of the light counterclockwise when wearing the headlamp. To adjust the beam into Bulls-Eye Spot mode, rotate the Twist Focus Ring bezel around the lens of the light clockwise when wearing the headlamp. The hinged adjustment allows you to tilt the headlamp downward to illuminate close objects. To adjust the tilt position of the headlamp, hold the body of the headlamp with one hand and tilt the body away from the back plate (which retains the strap), holding the back plate with a second hand (if necessary).

HEAD STRAP ADJUSTMENT:

To adjust the FL75R to fit your head, slide the buckles on the side head strap and top strap. It may be necessary to reposition the headlamp and battery pack on the side head strap once the headband is adjusted to the proper size.

HARD HAT SAFETY HELMET CLIP USE:

The FL75R includes helmet clips for use with hard hat style safety helmets. To use the helmet clips, loosen the side and top straps to fit the helmet and attach the clips to the side strap of the headlamp, evenly spaced with two on each side. Attach the headlamp to the safety helmet and attach the clips to the rim of the helmet. Some adjustment of the clip positions and head straps will be necessary for proper fit on safety helmets. NOTE: Clips are designed for use ONLY with HARD HAT style safety helmets. They are not acceptable for use on most sporting safety helmets.

MAINTENANCE:

Wipe the external body with a moistened with water or isopropyl alcohol. Allow alcohol to dry before use. Do not submerge.